



Model BFS450/Z Parts List

A = Standard Equipment

○ = Circuit Diagram

Fig.	Part No.	Description	Q'ty	Unit
1	450691-1	LOCK RING	1	PC.
2	158753-6	LOCATOR L COMPLETE	1	
D10		INC. 3,4		
3	424133-1	BRAKE PIN	1	PC.
4	424134-9	DUST SEAL RING	1	PC.
5	233967-9	RING SPRING 33	1	PC.
6	232245-4	LEAF SPRING	1	PC.
7	158755-2	LOCATOR BASE COMPLETE	1	PC.
8	911148-2	PAN HEAD SCREW M4X25	1	PC.
9	450689-8	LIGHT HOLDER	1	PC.
10	188559-8	HOUSING SET	1	
C10	810421-6	CAUTION LABEL	1	
D10		INC. 45		
11	865344-3	BFS450 NAME PLATE	1	
12	265995-6	TAPPING SCREW 4X18	9	PC.
13	214174-3	PLANE BEARING 14	1	
14	213262-3	O RING 18	1	PC.
15	421927-5	SLEEVE 20	1	PC.
16	232050-9	LEAF SPRING	1	PC.
17	216001-0	STEEL BALL 3.5	1	PC.
18	324925-7	SPINDLE	1	PC.
19	256509-2	SHOULDER PIN 8-10	1	PC.
20	267331-2	FLAT WASHER 25	1	PC.
21	267331-2	FLAT WASHER 25	1	PC.
22	234017-3	COMPRESSEION SPRING 25	1	PC.
23	267332-0	FLAT WASHER 26	1	PC.
24	223169-5	CLUTCH CAM C	1	PC.
25	216008-6	STEEL BALL 4	3	PC.
26	226670-9	HELICAL GEAR 48	1	PC.
27	211034-0	BALL BEARING 608	1	PC.
28	165115-1	RUBBER SLEEVE 10	1	PC.
29	214017-9	PLANE BEARING 5	1	PC.
30	253811-4	FLAT WASHER 5	1	PC.
31	154937-4	GEAR COMPLETE 18-44	1	PC.
32	214017-9	PLANE BEARING 5	1	PC.
33	213055-8	O RING 10	1	PC.
34	419304-3	F/R CHANGE LEVER	1	PC.
35	650603-6	SWITCH TG513SBA-1	1	PC.
36	643812-4	TERMINAL	1	PC.
37	631818-4	LIGHT CIRCUIT	1	PC.
38	638426-2	YORK UNIT	1	PC.
39	619216-2	ARMATURE	1	PC.
40	194427-5	CARBON BRUSH CB-440	1	SET
41	638433-5	BRUSH HOLDER COMPLETE	1	PC.
C10	231696-8	TORSION SPRING R	1	PC.
C20	231697-6	TORSION SPRING L	1	PC.
42	263032-0	RUBBER PIN 4	2	PC.
43	450692-9	FRONT COVER	1	PC.

	44	265995-6	TAPPING SCREW 4X18	2	PC.
	45	188559-8	HOUSING SET	1	
	C10	810421-6	CAUTION LABEL	1	
	D10		INC. 10		
A	A01	281220-7	HOOK	1	
A	A02	784211-2	PHILLIPS INSERT BIT 2-25	2	PC.
A	A03	784801-1	MAGNETIC BIT HOLDER 6.35-76	1	PC.
	D01	654208-4	RECEPTACLE	2	PC.
	D02	654510-5	INSULATED CONNECTOR 5.5-SD	2	PC.
		BFS450Z	TOOL ONLY		